


AVS SERVICE INSTRUCTIONS

STEP TYPE	Electric	Last Updated	19/6/06
CONTROL BOX	C112	Revision no:	1
TITLE	PDC Switch Positions		



	OPERATION	DEFAULT	MODIFIED
A	Step illumination	LINK 3 & 2	LINK 1 & 2
		Controlled by side light and step out.	Controlled by step operation.
B	Audible Warning	LINK 2 & 1	LINK 2 & 3
		Ignition controlled.	Permanent
C	Audible Warning	LINK ON	LINK NOT ON
		Works when not stowed.	Work when moving.

